

Warnings:

- * Risk of fire or electric shock.
- * **Disconnect all power before installing or servicing.**
- * Installation Instructions for qualified electricians only.
- * Install per National Electrical Code and local regulations.
- * Read Installation Instructions completely before installation.
- * Failure to follow Installation Instructions may void warranties.



VF3 ADJUSTABLE LED MODULE REPLACEMENT

THESE PRODUCTS MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

LED MODULE REPLACEMENT:

- 1.** Remove adjustable yoke, gimbal & LED assembly together by pulling down and disengaging the ball catch retainers from the housing. BE CAREFUL OF NOT PULLING OUT THE WIRING. USE QUICK DISCONNECTS AT POWER SUPPLY LINE.
- 2.** Turn the LED module assembly 1/8 counter clockwise to disengage from the gimbal key lock. Once disengaged continue to unscrew the aperture / retaining ring from the LED assembly and pull apart.
- 3.** Reverse process by inserting the replacement LED module into the gimbal. Screw back the aperture / retaining ring onto the module.
- 4.** Turn LED module assembly 1/8 clockwise to set into gimbal key lock.
- 5.** Connect power supply line. Push yoke assembly back into housing and firmly lock into ball catch retainers.

NOTE: ALL WORK MUST BE DONE WITH CIRCUIT OFF AND COMPONENTS SHOULD NOT BE INSTALLED WHEN ENERGIZED.

CAUTION:

- LEDs are ESD (Electro Static Discharge) sensitive devices that can be easily damaged if the proper ESD mitigating steps are not taken.
- LEDs are very sensitive to mechanical damage. Caution must be taken to avoid damage to the LEDs.
- ESD or mechanical damage voids all warranties.

